

# THERMAL IMAGING CAMERA METERS MET11-07



# THERMAL IMAGING CAMERA METERS MET11-07

Thermal imaging cameras are non-contact devices used to capture detailed images in low-light environments. It works by detecting infrared energy (heat) which interprets temperature as colour and converting it into an image in real-time. Red and yellow colours depicts warmer areas and purple or blue colours depict cooler areas.

## MET11-07 THERMAL IMAGING CAMERA METERS



Product Image Coming Soon

### SPECIFICATIONS

Model	MET11-07
Display screen	3.2 " full angle TFT/display screen
Infrared image resolution	220x160
visible image resolution	300,000 pixel
Field angle/shortest focus length	27°x35°/0.15 m
Thermal sensitivity	0.07 °C
Temperature measurement range	-20 °C~300 °C (-4 °F~572 °F)
Measurement accuracy	± 2 % digital/± 2 °C
Emissivity	Adjustable from 0.01 to 1.0
Frame rate of thermal images	9 Hz
Wavelength coverage	8-14 um
Focus mode	Fixed
Color palette	Rainbow, iron oxide red, cold color, black & white, white & black
View option	The integration of thermal image with 25% step length and visible image.
Storage medium	Built-in 3G (above 20 thousand image stored)
File format	JPG
USB	Micro USB 2.0
Power supply	Built-in rechargeable 18650 battery
Automatic power-off time	Selectable: 5 minutes/20 minutes/not power off automatically
Product size (length × width × height)	90×105×223 mm
Product weight	389 g
Work temperature	0 °C to 45 °C
Storage temperature	-20°C to 60°C
Relative humidity	< 85 % RH





**Biozef**

82 Wendell Avenue, STE 100, Pittsfield, MA, 01201, USA

Email: [info@biozef.com](mailto:info@biozef.com) | Website: [biozef.com](http://biozef.com)